


# Threading Material Through Dual Sensor

You may see an error on your control panel that is indicated by a flashing red 'Print Film' indicator or a flashing red 'Foil' indicator. This condition is easily corrected by correcting the threading of the material through the sensors.




The print film and foil sensors are located on the right hand side of your machine on the front.




Please ensure that the print film and foil are threaded between yellow marks on the sensors. Also check that the rolls of material are pushed onto the hubs as far as possible.

Note ... If you have just put a new roll of material on and start having problems with sensors, you probably don't have it pushed on far enough.



When threaded correctly, your machine will look like this picture.



If the material is fully assembled on the spindles and you have threaded it through the sensors as depicted and you are still experiencing problems, please feel free to call

**1-800-727-2543 inside the USA**

or

**330-698-4711**

You may also email us at [mpesho@euclidspiral.com](mailto:mpesho@euclidspiral.com).

Thank You,

Euclid® Spiral Paper Tube Corp.  
339 Mill St. - PO Box 458  
Apple Creek, OH 44606

[www.euclidspiral.com](http://www.euclidspiral.com)